

**AGUA4TLAV2**  
**AGUA7TLAV2**  
**AGUA9TLAV2**  
**AGUA12TLAV2**  
**AGUA14TLAV2**

## **OPERATION MANUAL**

INDOOR UNIT (Floor type)

Keep this manual for future reference.

## **MODE D'EMPLOI**

UNITÉ INTÉRIEURE (Type sol)

Conservez ce manuel pour toute référence ultérieure.

## **MANUAL DE FUNCIONAMIENTO**

UNIDAD INTERIOR (Tipo suelo)

Conserve este manual para posibles consultas futuras.

English

Français

Español



# OPERATION MANUAL

PART No. 9382567064



VRF system indoor unit (Floor type)

## CONTENTS

SAFETY PRECAUTIONS.....	1
NAME OF PARTS .....	1
MANUAL AUTO OPERATION .....	2
AIRFLOW DIRECTION .....	2
AIR OUTLET SELECTION .....	2
OPERATING TIPS .....	3
CLEANING AND CARE.....	3
TROUBLESHOOTING .....	5
SPECIFICATIONS.....	6

## SAFETY PRECAUTIONS

- Before using this product, read these “SAFETY PRECAUTIONS” thoroughly and operate in the correct way.
- The instructions in this section all relate to safety; be sure to maintain safe operating conditions.
- “WARNING” and “CAUTION” have the following meanings in these instructions:

 <b>WARNING</b>	This mark indicates procedures which, if improperly performed, might lead to the death or serious injury of the user.
 <b>CAUTION</b>	This mark indicates procedures which, if improperly performed, might possibly result in personal harm to the user, or damage to property.

### PRECAUTIONS ON USE

#### **WARNING**

- Do not keep exposing oneself to the direct airflow of air conditioner for a long time.
- Do not insert fingers or objects into the outlet port or other openings.
- Except for EMERGENCY, never turn off the main or sub breaker of the indoor units during operation. It will cause compressor failure or water leakage.  
When stopping the operation, stop the indoor unit by operating the control unit, converter or external input device and then cut the breaker. Make sure to operate through the control unit, converter, or external input device.
- If the power supply cord of this product is damaged, it should only be replaced by the authorized service personal, since special purpose tools and specified cord are required.
- If any refrigerant happens to leak, extinguish any flames, ventilate the room and get in touch with authorized service personnel.

#### **CAUTION**

- Provide occasional ventilation during use.
- Do not use in applications involving the storage of foods, precision equipment, or art works.
- Do not place animals or plants in the direct path of the airflow.
- Do not direct airflow at fireplaces or heating apparatus.
- Do not block or cover the inlet port and outlet port.
- Do not climb on, or place objects on, the air conditioner.
- Do not set flower vases or water containers on top of air conditioners.
- Do not hang objects from the indoor unit.
- Do not place anything below the indoor unit that should not get wet.
- Always turn off the electrical breaker whenever cleaning the air conditioner or the air filter.
- Do not pour water or cleaning solvent on the unit directly, or wash the unit with them.
- Do not expose the air conditioner directly to water.

- Do not operate the air conditioner with wet hands.
- Check the condition of the installation stand for damage.
- Operate only with air filters installed.
- Do not drink the water drained from the air conditioner.
- Do not apply any heavy pressure to radiator fins.
- Do not use flammable gases near the air conditioner.
- Do not touch the pipes during the operation.
- Ensure that any electronic equipment is at least 40 in (1 m) away from either the indoor or outdoor units.
- This product is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the product by a person responsible for their safety. Children should be supervised to ensure that they do not play with this product.

#### **NOTE:**


Switching the operating mode in the heat recovery system may require some time to prepare for operation. Please note that this is not a fault.

### PRECAUTIONS ON INSTALLATION

#### **CAUTION**

- Do not attempt to install this air conditioner by yourself.
- This unit contains no user-serviceable parts.  
Always consult authorized service personnel for repairs.
- When moving, consult authorized service personnel for removal or installation of the unit.
- The unit must be grounded.
- Make sure drain work is implemented properly for drainage.
- Avoid installing the air conditioner near a fireplace or other heating apparatus.
- When installing the indoor and outdoor unit, take precautions to prevent access to infants.

## NAME OF PARTS



- (1) Operating control panel
- (2) Air outlet selection switch
- (3) MANUAL AUTO button: This is used to operate the air conditioner while the remote controller is not available.
- (4) Indicator lamps
- (5) Timer indicator lamp (orange): It turns on while timer is working.
- (6) Operation indicator lamp (green): It turns on while operating.
- (7) Filter indicator lamp (red): It turns on when the air filter became dirty. Clean the filter referring to “CLEANING AND CARE”. It turns off when reset by the remote controller after cleaning.

- (8) Remote control signal receiver: This is the place to receive the signals from the remote controller.
- (9) Intake grille
- (10) Front panel
- (11) Air filter
- (12) Horizontal louver
- (13) Vertical louver (behind the horizontal louver and damper)
- (14) Damper
- (15) Air cleaning filter
- (16) Rope
- (17) Drain hose

### Control unit (optional)

Types of remote controllers:

- Wireless remote controller
- Wired remote controller
- Simple remote controller

For operation method, refer to the operation manual of each control unit.

## MANUAL AUTO OPERATION

Use the Manual auto operation in the event the remote control unit is lost or otherwise unavailable.



**CAUTION**

Do not press the MANUAL AUTO button with wet hands or pointed objects, otherwise an electric shock or malfunction may occur.

### Starting Operation

**Press the MANUAL AUTO button on the operating control panel.**

The operation starts in the setting below.

Operating mode	Auto: When Auto mode cannot be selected, it will operate in the same mode as the other indoor unit in the same system. (When no indoor unit is operating in the same system, the air conditioner will operate in the Cooling mode.)
Fan speed	Auto
Setting temperature	74°F (23°C)

### Stopping Operation

**Press the MANUAL AUTO button on the operating control panel.**

### Emergency Heat

\* It is available when this function is enabled. Please consult an authorized service personnel as to whether this function is enabled.

#### Set Emergency heat

**During heating operation, press the MANUAL AUTO button on the operating control panel.**

Auxiliary heater will be primary heater, and the outdoor unit will stop. The Operation indicator lamp (green) blinks during the Emergency heat operation. (3 seconds on, 1 second off.)

#### Cancel Emergency heat


**During the Emergency heat operation, press the MANUAL AUTO button on the operating control panel.**

## AIRFLOW DIRECTION

### Up/down airflow direction


The up/down airflow direction can be controlled with the remote controller.

Cooling, Dry and Heating



### Left/right airflow direction

The left/right airflow direction can be manually set by adjusting the vertical louvers.



**CAUTION**


Always adjust the vertical louvers when the damper is open. Opening the damper forcibly with hands can cause damper to malfunction.

## AIR OUTLET SELECTION


With this function, air comes out simultaneously from the upper and lower air outlets so that the room can be cooled or heated effectively. This function is set using the switch behind the front grille of the Indoor unit. (This function is available in cooling and heating operation.)

### How to set the out air outlet

#### Upper air outlet only



#### Upper and lower air outlets








### NOTES:

Set the air outlet selection switch to the end. Otherwise, air outlet cannot be selected as intended.

## Description of operation

### (When set to the upper and lower air outlets)

Cooling mode		Dry mode	Heating mode	
				
Upper and lower airflow	Upper airflow	Upper airflow only	Upper and lower airflow	Upper airflow
Room temperature and set temperature are different.	Room temperature is close to set temperature, or the air conditioner has operated for 1 hour.	—	Airflow temperature is high.	Airflow temperature is low. (During defrosting operation, start of operation, etc.)

## OPERATING TIPS

### Operation and Performance

#### About priority state and standby state

- Multiple indoor units can be connected within the same system. Depending on the system, choice of operating mode are limited.

#### Cooling priority state:

When the other indoor units within the same system operate in cooling or dry mode, heating cannot be selected at the same time.

#### Heating priority state:

When the other indoor units within the same system operate in heating mode, cooling and dry mode cannot be selected at the same time.

#### Standby state:

The standby state activates when 2 or more indoor units start up at the same time in different mode. Any indoor unit other than priority mode will wait in standby state until priority mode changes (operation starts as soon as priority is switched).

At this time, the Operation indicator lamp (green) will turn on and the Timer indicator lamp (orange) will blink.

#### Low ambient cooling

- When the outdoor temperature drops, the outdoor unit's fans may switch to Low Speed, or one of the fans may stop intermittently.

#### Heating performance

- Heating mode operates on the heat pump principle, absorbing heat from outdoor air and transferring that heat indoors. As a result, the operating performance is reduced as outdoor air temperature drops. If you feel that insufficient heating performance is being produced, we recommend you use this air conditioner in conjunction with another type of heating appliance.
- Heating mode heat your entire room by recirculating air throughout the room, with the result that some time may be required after first starting the air conditioner until the room is heated.

### Automatic defrosting

- When using the Heating mode under conditions of low outdoor air temperature high humidity, frost may form on the outdoor unit, resulting in reduced operating performance. In order to prevent this kind of reduced performance, this unit is equipped with Automatic defrosting function. If frost forms, the air conditioner will temporarily stop, and the defrosting circuit will operate briefly (for about 4 to 15 minutes). During Automatic defrosting operation, the Operation indicator lamp (green) will blink.

### Oil recovery operation

- Periodically, the oil recovery operation is performed in order to return compressor oil to the outdoor unit. During oil recovery operation, the Operation indicator lamp (green) will blink (for about 10 minutes).

### Temperature and humidity range

- The temperature and humidity required for operating this product is as shown in the following table.

	Cooling/Dry Mode	Heating Mode
Outdoor temperature	Please refer to the specifications of outdoor units.	
Indoor temperature	About 64 to 90 °F DB (18 to 32 °C DB)	About 50 to 86 °F DB (10 to 30 °C DB)
Indoor humidity	About 80% or less	

- If the air conditioner is operated under higher temperature conditions than those listed, the built-in protection circuit may operate to prevent internal circuit damage. Also, during Cooling and Dry modes, if the unit is used under conditions of lower temperature than those listed above, the heat-exchanger may freeze, leading to water leakage and other damage.
- If the unit is used for long periods under high-humidity conditions, condensation may form on the surface of the indoor unit, and drip onto the floor or other objects underneath.
- Do not use this unit for any purposes other than the Cooling, Heating, Dehumidifying, and air-circulation of rooms in ordinary dwellings.

## CLEANING AND CARE


### CAUTION

- Before cleaning the unit, be sure to stop the unit and disconnect the power supply.
- Do not stand on an unstable platform when cleaning.
- When removing and replacing the air filters, be sure not to touch the heat exchanger, as personal injury may result.
- Be sure the intake grille is installed securely.
- Do not clean the inside of the unit by yourself. To clean the inside, always consult authorized service personnel.
- When cleaning the unit's body, do not use water hotter than 104°F (40°C), harsh abrasive cleansers, or volatile agents like benzene or thinner.
- If dirt is allowed to accumulate on the air filter, airflow will be reduced, lowering operating efficiency and increasing noise. During periods of normal use, the air filters should be cleaned every 2 weeks.

## Cleaning the intake grille

### 1. Remove the intake grille.

- (1) Place your fingers at both top indicator of the intake grille, and pull forward; if the intake grille seems to catch part way through its movement, continue pulling down to remove.
- (2) Unhook the ropes which holds the intake grille.




### 2. Clean with water.

Remove dust with a vacuum cleaner; wipe the unit with warm water, then dry with a clean, soft cloth.

### 3. Replace the intake grille.


- (1) Hook the ropes.
- (2) Set the left and right mounting shafts into the bearings at the bottom of the panel.
- (3) Press the place where the mark on the diagram indicates and close the intake grille.



## Cleaning the air filter

### 1. Open the intake grille, and remove the air filter.

Push down the air filter's handle, disconnect the 2 upper tabs, and pull out.




### 2. Remove dust with a vacuum cleaner or by washing.

After washing, allow to dry thoroughly in a shaded place.

### 3. Replace the air filter and close the intake grille.

- (1) Align the sides of the air filter with the panel, and push in fully, making sure the 2 upper tabs are returned properly to their holes in the panel.



- (2) Close the intake grille.


- Dust can be cleaned from the air filter either with a vacuum cleaner, or by washing the filter in a solution of mild detergent and warm water. If you wash the filter, be sure to allow it to dry thoroughly in a shady place before reinstalling.
- If dirt is allowed to accumulate on the air filter, airflow will be reduced, lowering operating efficiency and increasing noise.
- During periods of normal use, the Air Filters should be cleaned every two weeks.

• When used for extended periods, the unit may accumulate dirt inside, reducing its performance. We recommend that the unit be inspected regularly, in addition to your own cleaning and care. For more information, consult authorized service personnel.

• When shutting down the unit for one month or more, first allow the fan mode to operate continuously for about one-half day to allow internal parts to dry thoroughly.

## Air cleaning filter installation

### 1. Open the intake grille and remove the air filters.




### 2. Install the air cleaning filter set (set of 2).

Set the air cleaning filter into the panel.


Catch it on 5 places of picks.

(3 places of upper parts and lower part 2 places.)





### 3. Install the 2 air filters and close the intake grille.




- When air cleaning filters are used, the effect will be increased by setting the fan speed to "High".

#### Replacing the air cleaning filter

Replace filters with the following components (purchased separately).

- Apple-catechin filter: UTR-FC03-2
- Ion deodorization filter: UTR-FC03-3


### 1. Open the intake grille and remove the air filters.



### 2. Replace them by two new air cleaning filters.

- (1) Remove the old air cleaning filters in reverse order of their installation.
- (2) Install in the same way as for installation of the air cleaning filter set.

### 3. Install the 2 air filters and close the intake grille.



#### In regard to the air cleaning filters

##### Apple-catechin filter (1 sheet)

- The filters are disposable filters. (They cannot be washed and reused.)
- For storage of the filters, use the filters as soon as possible after the package has been opened.
- (The air cleaning effect decreases when the filters are left in the opened package)
- Generally, the filters should be exchanged about every 3 months.

Please buy dedicated Apple-catechin filter (UTR-FC03-2) (Sold separately) to exchange the used dirty air cleaning filters.

##### Ion deodorization filter (1 sheet) - light blue

- The filters should be exchanged about every 3 years so as to maintain the deodorizing effect.

Please buy dedicated Ion deodorization filter (UTR-FA13-2) (Sold separately) when exchanging the filters.

#### Maintenance of ION DEODORIZATION FILTER

In order to maintain the deodorizing effect, please clean the filter in the following way every 3 months.

- (1) Remove the filter.
- (2) Clean with water and dry in the air.
  - 1) Flush the filters with high-pressure hot water until the surface of the filters are covered with water. Please flush with diluent neutral detergent. (Never wash by reaming or rubbing, otherwise it will damage the deodorizing effect.)
  - 2) Rinse with water flow.
  - 3) Dry in shade.
- (3) Reinstall the filter.

#### Cleaning body

Wash the body with warm water, and then dry with a clean and soft cloth.

#### When not using for an extended period

If you have shut down the indoor unit for 1 month or more, perform the FAN operation for half a day to dry the internal parts thoroughly before you perform normal operation.

#### After extended non-use of the unit

Leave the breaker on for at least 12 hours before starting operation when it is to be used again.

#### Additional inspection

After long period of use, accumulated dust inside the indoor unit may reduce the product performance even if you have maintained the unit with instructed daily care or cleaning procedures written in this manual.

In such a case, a product inspection is recommended.

For more information, consult authorized service personnel.

## TROUBLESHOOTING

### The following conditions are not breakdowns or operation failures.

#### Doesn't operate immediately:

- If the unit is stopped and then immediately started again, the compressor will not operate for about 3 minutes, in order to prevent fuse blowouts.
- Whenever the electrical breaker is turned off then on again, the protection circuit will operate for about 3 minutes, preventing unit operation during that period.

#### Airflow is weak or stops:

- When Heating operation is started, indoor unit's fan may temporarily stop, to allow internal parts to warm up.
- During Heating operation, if the room temperature rises above the thermostat setting, the outdoor unit will stop, and the indoor unit's fan will stop. If you wish to warm the room further, set the thermostat for a higher setting.
- During oil recovery operation, the airflow may stop for approximately 10 minutes. (Refer to "OPERATING TIPS")
- During Heating operation, the unit will temporarily stop operation (between 4 and 15 minutes) as the Automatic defrosting mode operates. (Refer to "OPERATING TIPS")
- The fan may operate at low speed during Dry operation or when the unit is monitoring the room's temperature.
- In the monitoring in the Auto mode, the fan will operate at low speed.

#### Indicator lamps are blinking:

- The Operation indicator lamp (green) flashes:  
An oil recovery operation is being performed. (Refer to "OPERATING TIPS")  
The Automatic defrosting operation is being performed. (Refer to "OPERATING TIPS")
- The Operation indicator lamp (green) and Timer indicator lamp (orange) are blinking alternately:  
It has recovered from a power outage.
- The Operation indicator lamp (green) and Timer indicator lamp (orange) are blinking simultaneously:  
It is operating in the test run mode. Ask a manager as there may be maintenance being conducted.
- The Operation indicator lamp (green) is on and the Timer indicator lamp (orange) is blinking:  
This is the standby state. (Refer to "OPERATING TIPS")

#### Noise is heard:

- In the following conditions there are sounds of water flowing from the indoor unit and the operation sound becomes loud. These are the refrigerant flow sound.  
When operation starts  
When oil recovery operation finishes  
When Automatic defrosting operation finishes
- During operation, a slight squeaking sound may be heard. This is the result of minute expansion and contraction of the panel due to temperature changes.
- During Heating operation, a sizzling sound may be heard occasionally. This sound is produced by the Automatic defrosting operation. (Refer to "OPERATING TIPS")

#### Smells:

- Some smell may be emitted from the indoor unit. This smell is the result of room smells (furniture, tobacco, etc.) which have been taken into the air conditioner.

#### Fog comes out of the indoor unit:

- During Cooling operation, a thin mist may be seen emitted from the indoor unit. This results from the sudden Cooling of room air by the air emitted from the air conditioner, resulting in condensation and misting.

#### Steam comes out of the outdoor unit:

- During Heating operation, the outdoor unit's fan may stop, and steam may be seen rising from the unit. This is due to the Automatic defrosting operation. (Refer to "OPERATING TIPS")

#### Water is produced from the outdoor unit:

- During Heating operation, water may be produced from the outdoor unit due to the Automatic defrosting operation.

### The following conditions may not be breakdowns so check again.

#### Doesn't operate at all:

- Has there been a power failure?
- Has a fuse blown out, or a circuit breaker been tripped?
- Is the main power switch set to the OFF position?
- Are you trying to engage in an operation different from the priority state? (Refer to "OPERATING TIPS")
- Is it in standby state? (Refer to "OPERATING TIPS")

#### The operation mode cannot be changed:

- Are you trying to change to an operation different from the priority conditions? (Refer to "OPERATING TIPS")

#### Poor Cooling (or Heating) performance:

- Did you adjust the temperature setting correctly?
- Is the air filter dirty? (Refer to "CLEANING AND CARE")
- Are the air conditioner's inlet port or outlet port blocked?
- Is there a window or door open?
- In the case of Cooling operation, is a window allowing bright sunlight to enter? (Close the curtains.)
- In the case of Cooling operation, are there heating apparatus and computers inside the room, or are there too many people in the room?
- Is the fan speed set to low?

#### Temperature does not fall down well.

- Temperature may not fall down depending on the room conditions. (While high humidity or the room temperature is high.) (Refer to "OPERATING TIPS")  
Set the temperature lower than the room temperature and use it.

### In the following situations, stop operation immediately and get in touch with authorized service personnel.

- The problem cannot be solved even when the troubleshooting checks have been performed.
- The Filter indicator lamp (red) is blinking very fast.
- The wired remote controller or simple remote controller indicate "Er" (when connected).
- It has burning smell.

## SPECIFICATIONS

MODEL		AGUA 4TLAV2	AGUA 7TLAV2	AGUA 9TLAV2	AGUA 12TLAV2	AGUA 14TLAV2
POWER SOURCE		208/230 V ~ 60 Hz				
AVAILABLE VOLTAGE RANGE		187 to 253 V				
COOLING CAPACITY	Btu/h (kW)	4,000 (1.2)	7,500 (2.2)	9,500 (2.8)	12,000 (3.5)	14,000 (4.1)
HEATING CAPACITY	Btu/h (kW)	4,400 (1.3)	9,500 (2.8)	10,900 (3.2)	13,500 (4.0)	15,600 (4.6)
SOUND PRESSURE LEVEL						
HIGH	dB [A]	35/36 (*1)	37	38	42	46
MED - HIGH	dB [A]	33	35	36	39	42
MED	dB [A]	31	33	34	37	39
MED - LOW	dB [A]	30	31	31	35	36
LOW	dB [A]	28	29	29	33	33
QUIET	dB [A]	22	22	22	30	30
DIMENSIONS & WEIGHT						
HEIGHT	[in (mm)]	23-5/8 (600)				
WIDTH	[in (mm)]	29-1/8 (740)				
DEPTH	[in (mm)]	7-7/8 (200)				
WEIGHT	[lbs (kg)]	33 (15)				

\*1: This value is "cooling operation/heating operation".

#### Acoustic Noise Information:

The maximum sound pressure level is less than 70 dB (A) for both indoor unit and outdoor unit. According IEC 704-1 and ISO 3744.

**FUJITSU GENERAL LIMITED**

3-3-17, Suenaga, Takatsu-ku, Kawasaki 213-8502, Japan