

#### Reliability Making Money

#1

# ... being DUMB is expensive







### ... so how many spare engines do I need for a 3-year period

for 1 truck?


# ... dumb way #1


... textbook








#### ... the Poisson Distribution 100 ... probability mass function 90probability (%) 80~ 70
















... total # of failures







... total # of failures

### ... why is this dumb?

#### the (random) hand of failure



time to failure (TTF)




time to failure (TTF)


# ita/e fatala

ത


#### ... accumulating damage wear-out Corrosion ... fatigue ate at which ' that is still ng - fails ... cveep ... diffusion ... wear ... oxidation ... lubricant contamination


time to failure (TTF)







# ... and our engine?







... includes starting with engines at random points in their service life







... total # of failures





... total # of failures





### ... \$ USD 1.4 - 1.6 million

... what will happen to the


2 (of the 5)

... and how much does it cost to PROPERLY wavehouse these two engines?


engines that are all but guaranteed to be left over after 3 years?

## ... dumb(er) way #2


### ... OLD textbook




... total # of failures



... total # of failures






... interval ... failure # of spares vate  $\lambda t + z_{CI} \sqrt{\lambda t}$ ... standard normal for this level variable of confidence

... this approximation was used back when the only way to solve statistical problems was through a *normal distribution table* in the back of textbooks.


... and technological advances in medicine allowed us to evadicate SMALLPOX in 1979

... (next level) dumb way #3

### ... several BOKs



... total # of failures



... heve is the movemal approximation




... 150 systems mm/x 150

= 26.2 spaves

.. total # of failures

## ... but remember the example we just went through?



... for a fleet of 150 ... total # of failures

## 4 spares ... fleet 27 spares ... dumb

## ... truly dumb way #4 ... old guy guesses

... assuming a sevies system

... number of each component in the system

 $N_1 \lambda_1 + N_2 \lambda_2 + ... + N_n \lambda_r$ 

... generic component failure rates from some book (like MIL-HDBK-217F)

 $N_{\parallel}\Pi_{Ql}\lambda_{\parallel}+N_{2}\Pi_{Q2}\lambda_{2}+...+N_{n}\Pi_{Qn}\lambda_{n}$ 

... these are called quality factors

which we get from ... witchcraft?



 $N_{1}\Pi_{Q1}\Pi_{e1}\lambda_{1} + N_{2}\Pi_{Q2}\Pi_{e2}\lambda_{2} + ... + N_{n}\Pi_{Qn}\Pi_{en}\lambda_{n}$ ... these are called

### environmental stress factors

which we get from ... the same witch?


... which means we are not even pretending to use reliability engineering to get this





environmental stress factors

which we get from ... the same witch?



### EOQ

... and this might not align with Poisson distribution spare part analysis ... but this is only a

rule

and not an optimized figure or formula

# ... how do you do yours?



