



Fiber Optics For Sale Co.

COMPLETE SUPPLY SOLUTIONS

SIMPLEX/DUPLEX PULLING EYE F1-1001-BR

1. Slide one end of the patchcord to be pulled up into the cable netting. Make sure that the connectors are placed up towards the top of the netting.
2. Tape the open end of the cable netting down onto the strength member of the pulling eye. We recommend using electrical tape. The tape should cover an area from 1" below the end of the cable netting.
3. Braid the two strength members around your cable. Tape a 4" section of the strength member to your cable. Starting just below the cable netting, spiral wrap the tape around the cable. Your cable is now ready to be pulled.

To reuse the pulling eye, carefully remove the tape you applied, then repeat steps 1-3.

