



These photos are of the LNE brake arrangement. The Maine Central is the same in all respects except the components are located as noted in the diagram shown above.

your preference, add reweigh and repack stencils, and chalk marks, and your model is ready. Congratulations!

Parts List

- Red Caboose 40' ARA Box Car kit
- Resin castings (roof, doors, and details)
- Sill steps
- 18" straight and drop grab irons
- Tichy AB brake sprue
- Strip styrene
- Wire (0.008", 0.010", 0.012", 0.015")
- Decals

Optional

- Tahoe Model Works Buckeye trucks
- Couplers
- Strip styrene - various
- Chain