



The Block is hollowed out
 to fit the chock -
 Two bolts go through the
 block - they are located under
 the ends of the chock
 Fair Winds Eric
 SM 376 Kimberlite