



CASTORO

CELLARS

Installing Key Keg: Changing From the Free Flow System

- 1) Switch off the gas to the keg.
- 2) Unscrew hex nut connector bolts on both gas and wine tubing from old system coupler using wrench provided.
- 3) Attach Key Keg Coupler to gas and wine tubing by screwing hex nut connector bolts from lines to the threading on the new coupler. **Wine line is on top of coupler, gas line is on the side of the coupler.** Tighten with wrench provided.
- 4) Remove caps on top of the new Key Keg.
- 5) With metal handle on Key Keg coupler in the up position, twist the coupler clockwise on top of Key Keg until it locks.
- 6) Push lever down to lock in place.
- 7) Turn gas back on.
- 8) Wine is ready to pour!

Changing a Key Keg

- 1) Switch off the gas to the keg.
- 2) Twist off Key Keg coupler counter clockwise to remove from top of keg; keep gas and wine tubing attached to coupler.
- 3) Remove caps from the top of the new Key Keg.
- 4) With metal handle on Key Keg coupler in the up position, twist the coupler clockwise on top of Key Keg until it locks.
- 5) Push lever down to lock in place.
- 6) Turn gas back on.
- 7) Wine is ready to pour!

