

Refractometer 55586

- Easy on-site measurement of antifreeze and heat transfer fluids
- Adjustable eye piece
- Easy to use
- · Quality, maintenance-free instrument



Accurate, easy-to-use antifreeze testing instrument uses an adjustable eye piece to measure refracted light given off by all glycol-based antifreeze products, to determine the concentration of treatment present in the system.

Application

The refractive Index of a material is an optical measurement of its ability to bend a beam of light entering it. The refractive index may be used to determine the concentration of a material when dissolved in water, due to the difference in refractive index between water and the material being monitored. All glycol-based antifreezes will refract light and this property can be used to determine the concentration of treatment present.

How to use:

The Refractometer has an adjustable eyepiece. If the user normally wears spectacles, it may be that the scale is sharper without them. The scale is calibrated for use at $20\pm2^{\circ}$ C with the graphs provided. If used in temperatures outside of this range, it is advisable to recalibrate - please refer to steps 1 to 3 of the instruction leaflet supplied with the product. When determining the concentration of antifreeze in a water system, it is advisable to take the average of two or three readings, if time permits.

Test Procedure:

Take a small sample of test solution into a clean container. Ensure that the sample does not contain grit that could scratch the prism. Allow the samples to cool to room temperature $(20\pm2^{\circ}C)$ before testing. Very hot solutions could crack the glass prism and will also give inaccurate results. Open the illuminator plate situated at the end of the instrument furthest away from the eyepiece and place a drop or two of test sample on the prism. Use only plastic applicator rods as the prism glass is relatively soft and can be easily scratched. Close the illuminator plate and direct the instrument towards a convenient light source. Looking through the eyepiece, a circular field will be seen with a vertical scale down the centre. When an optically active material is present in the sample, the field will also be split horizontally into dark and light areas. The position at which the demarcation between light and dark crosses the vertical scale is the point from which the reading should be taken. Select an appropriate scale for the type of antifreeze being tested.



Read off the concentration of antifreeze and compare with the guideline concentrations.

Package, Handling & Safety

Fernox Refractometer is supplied in a plastic case, and an instruction leaflet with usage details.

Single Item		Outer Carton	
Height mm	50	Outer Height mm	340
Width mm	225	Outer Width mm	510
Depth mm	75	Outer Depth mm	520
Weight kg	0.240	Outer Weight kg	12.200
Barcode EAN	5014551555860	Transit Type	N/A
		Units per carton	50
		Cartons per layer	0
		Total units per transit layer	0
		Layers per transit type	0
		Total units per transit type	0

Last modification 09-10-2023 (d/m/y)