


Kitchen - eno

Single-lever mixer with pull-out spout with spray function - polished chrome

Article number: 33 875 760-00 0010 [001]



Kitchen - eno

Single-lever mixer with pull-out spout with spray function - polished chrome

Article number: 33 875 760-00 0010 [001]

Spare parts list

Number	Item Number	Designation	Number of units
1	09 20 76 001-00	handle	1
2	09 31 20 109 90	plug	1
3	09 31 11 030 90	pin	1
4	09 28 30 012-00	cover	1
5	09 14 10 102 90	seal	1
6	09 24 04 270 90	nut	1
7	04 28 10 148 00 90	accessories	1
8	90 15 05 062 00 90	cartridge	1
9	04 30 02 121 00-00	hose	1
10	90 24 03 255 00-00	nut	1
11	09 23 01 039 90	sieve	1
12	04 12 11 102 00-00	shower	1
13	09 14 15 029 90	ring	1
14	09 28 10 144 90	ring	1
15	09 14 10 034 90	seal	1
16	09 27 76 001-00	rosette	1
17	09 14 10 036 90	seal	1
18	04 30 04 098 00 90	hose	2
19	04 30 11 040 00 90	fixing set	1
20	04 28 20 066 00 90	pipe	1
21	04 24 04 222 00-00	adaptor	1
22	04 23 30 031 01-07	threaded connector	2
23	09 24 04 222 10-00	adaptor	2
24	04 21 50 010 00 90	accessories	1
25	09 30 03 038 90	hose	1
26	90 24 03 253 00 90	adaptor	1
27	09 23 01 095 90	back-flow preventer	1
28	09 16 01 023 90	ring	1
29	09 30 09 031 90	key	1