



3-thread flatlock, narrow and wide

Stitch programs 13 and 14

If all thread tensions are set correctly, thread looping is right at the edge of the fabric. The upper looper (red) and the needle (blue) meet at the edge of the material. The lower looper (yellow) also is at the edge as a straight piece of thread along the edge.



The needle thread does not go all the way to the fabric edge (too tight).

Adjust the needle thread tension (blue) to a lower setting and/or the lower looper thread (yellow) to a higher setting.



The upper looper thread (red) appears on the underside of the fabric.

Adjust the red thread tension to a higher setting and/or the needle thread (blue) to a lower setting.

2-thread flatlock, narrow and wide

Stitch programs 05 and 06

If all the thread tensions are set correctly, the looper and needle threads will meet on the edge of the fabric.

Note: To sew the 2-thread flatlock attach the converter as described on page 2-29.

The needle thread is too loose or the lower looper thread (yellow) is too tight.

Adjust the corresponding needle thread tension to a higher setting and/or change the yellow thread tension to a lower setting.

The lower looper thread (yellow) is too loose and/or the needle thread is too tight.

Adjust the yellow thread tension to a higher setting and/or change the corresponding needle thread tension to a lower setting.

