

Control Change Messages (Appendix 3 continued)

CC#	PARAMETER/SETTING	VALUE RANGE ¹
07	Master Volume	(0 – 127)
11	Current Expression Pedal Assignment	(0 – 21)
85	Effects On/Off ²	OFF = (0 – 63), ON = (64 - 127)
102	Gain	(0 – 127)
103	Volume	(0 – 127)
104	Treble	(0 – 127)
105	Middle	(0 – 127)
106	Bass	(0 – 127)
107	reserved	(0 – 127)
108	Master Volume	(0 – 127)
109	Reverb Level	(0 – 127)
110	Reverb Time	(0 – 127)
111	Reverb Dwell (Input)	(0 – 127)
112	Reverb Diffusion	(0 – 127)
113	Reverb Tone	(0 – 127)
114	Mod. F/X Level	(0 – 127)
115	Mod. F/X Parameter 1	(0 – 127)
116	Mod. F/X Parameter 2	(0 – 127)
117	Mod. F/X Parameter 3	(0 – 127)
118	Mod. F/X Parameter 4	(0 – 127)
119	Tap Interval ³	(0 – 127)
120	Delay Level	(0 – 127)
121	Delay Parameter 1 (Delay Time)	(0 – 127)
122	Delay Parameter 2 (Feedback)	(0 – 127)
123	Delay Parameter 3	(0 – 127)
124	Delay Parameter 4	(0 – 127)

Table Notes:

¹The Cyber-Deluxe™ amplifier Continuous Controller resolution is 0-127. (It will not accept 16,384 step sizes.)

²Effects On/Off does not affect Reverb.

³Tap Interval Continuous Controller number is defined by the Fender® Cyber Foot Controller™ MIDI device.