



SETUP GUIDE

BLACKBOOK 15 (W335XX)

1



- 1 - Webcam
- 2 - Microphone
- 3 - Power Button
- 4 - Touchpad

QUICK LAPTOP TOUR



- 5 - USB 3.0
- 6 - USB 3.0
- 7 - Headphone Port
- 8 - Microphone Port
- 9 - USB 2.0
- 10 - USB 2.0
- 11 - SD Card Reader
- 12 - Power Connector
- 13 - HDMI Port
- 14 - LAN Port (RJ45)
- 15 - Display Port
- 16 - USB 3.0
- 17 - USB Type C

2

CONNECTING POWER ADAPTER



3

POWER BUTTON 'ON'



Hold down the power button for 1-2 seconds

Then follow the Windows Setup prompts


4

INTERNET SECURITY INCLUDED

For your convenience every Venom BlackBook comes standard with a full 12 month subscription of paid Internet Security.

Ensure that you activate your Internet Security by entering the product key provided.

The product key and setup instructions can be found on the Internet Security software packaging which is provided in the product box.



5

REGISTER YOUR VENOM

Visit www.venomhelpdesk.com/newaccount or click on the shortcut provided on your Venom BlackBook Windows desktop screen (🔗 icon).

Now you can create a Venom Help Desk account or log in if you have one already.

Once logged into your account, register your Venom BlackBook by:

- Entering in the serial number
- Selecting the place of purchase
- Uploading an image or PDF of your invoice



POST SETUP INFORMATION

USB RECOVERY DRIVE


Note: You are not required to use this device upon receipt of your new computer

This device is useful in the event you need to restore your Venom software back to factory settings. Please note, operating this device will erase all data stored on your computer, therefore it is important to back up your data before using this device.

How to use:

1. Connect USB Recovery Drive to a USB Port
2. Power on your BlackBook
3. At initial startup, press the 'F7' key two or three times to bring up menu
4. When the menu appears, select Kingston & press 'Enter'
5. Follow the prompts to recover the Operating System
6. Select which disk to install Windows on (this is usually the smallest SSD present)
7. You have the option to format & wipe any remaining drives. This is optional

Do not lose or modify this device.




WARRANTY & SUPPORT

In the event that you require after sales support you can simply create a ticket via the online Venom Help Desk.


To submit a ticket;

Visit www.venomhelpdesk.com or click on the shortcut provided on your Venom BlackBook Windows desktop screen (🔗 icon).

- Login
- Submit a ticket



KEYBOARD HOT KEYS DIAGRAM




FUNCTION KEY DEFINITIONS

F1	F2	F3	F4	F5	F6	F7	F8	F9	F10	F11	F12
Sleep	Windows Key Lock	External Display Options	Wi-Fi	Touchpad Lock	Keyboard Backlight Down	Keyboard Backlight Up	Mute	Volume Down	Volume Up	Brightness Down	Brightness Up

Example: Press 'Fn' and 'F1' key to activate sleep mode

CONTROL CENTER

The Venom BlackBook comes with an RGB Mechanical Keyboard. The keyboard backlight can be customised via the Venom Control Center software. A shortcut has been provided on the Venom BlackBook Windows desktop screen (⚙️ icon).



WINDOWS UPDATES

Windows updates are automatic. Your computer may run slower than usual immediately after the initial setup. This is because Windows updates may be running in the background. Your computer may need to restart after these updates.



DO's




OPEN FROM THE MIDDLE

Opening the lid by holding it from the middle will avoid putting uneven pressure on your computer's hinges.



USE ON FLAT, HARD SURFACE

Always use your Venom on a flat, hard surface. Do not use on carpets, bed spreads, laps, etc.



BATTERY DEEP CYCLING

In order to calibrate and condition a new battery, deep cycling is recommended. Charge the battery up to 100% and then let it discharge down to 2 or 3% capacity. Continue this process for the first 6 cycles to maximise the efficiency of the battery. You may use the computer freely during this process.



SHUT DOWN CORRECTLY

Always shut down your Venom correctly by going to the Windows Start Menu, selecting the power option and then clicking shut down.

DON'T's



DON'T APPLY PRESSURE ON SCREEN

Do not put anything heavy or apply pressure on the screen as this could cause damage.



DON'T SPILL LIQUID

Keep your computer away from liquid at all times.



DON'T KNOCK THE POWER CONNECTOR

Avoid knocking or bumping the connected power adapter as this could cause damage.



DON'T CARRY THE LAPTOP INCORRECTLY

Avoid carrying the laptop from the front whilst open. Always use two hands on either side or put your hand underneath to evenly disperse the weight.