

BRILLIANTSPA PRO™

PROFESSIONAL QUALITY
JEWELRY STEAM CLEANER




GEMORO®
The Sparkle Experts

Item # 0384

INSTRUCTIONS FOR USE & SAFETY PRECAUTIONS

Congratulations on your purchase of the amazing GemOro BrilliantSpa PRO! The professional grade BrilliantSpa PRO has been factory tested for performance, as well as safety, and does an incredible job cleaning jewelry and more in only seconds.

Please be aware that not all jewelry or items in general are suitable to be cleaned by a steam cleaner. Always confirm if the jewelry or other item may be cleaned with steam prior to cleaning it with the BrilliantSpa PRO.

SPECIFICATIONS

Power Voltage: 120V AC

Rated Frequency: 60Hz

Rated Power: 1000W

INCLUDED PARTS & ACCESSORIES

1. Triple steam jet fine mist nozzle.
2. Combination water residue collection and fill cup.
3. Funnel.
4. On/Off power switch.
5. Power cord receptacle.
6. Premium chrome plated steam activation lever.
7. LED indicator for steamer power and ready.
8. LED illuminated cleaning zone.
9. Water fill cap.
10. Top storage compartment for tweezers and rear hook for holding handheld basket.
11. Scratch resistant, plastic coated stainless steel tweezers and handheld clamshell style stainless steel mesh basket for holding rings, bracelets, diamond studs, and more.
12. Optional accessories (sold separately):
 - Stainless steel clip-on steam basket (Item #0379-BASKET).
 - Steam residue tray (Item #0379-TRAY).



EASY TO USE QUICK REFERENCE GUIDE

DO NOT PLUG IN YET!

1. Place the BrilliantSpa PRO on your counter near an electrical outlet.
2. Carefully unscrew the water fill cap, remove it and insert the funnel in the hole where the fill cap was located.
3. Fill the combination water residue collection and fill cup with regular tap water to the indicated MAX FILL line noted on the cup, and while the tank is completely empty, slowly pour it into the steamer's funnel. Repeat this a second time to fill the steamer's tank to the optimal level.



4. Replace the fill cap by hand tightening. Do not over-tighten.
5. Plug it in, and then flip the rear power switch to the "I" position to turn it on.
6. The red LED indicator shows it is heating up the water in its tank and building up pressure. When the green LED lights up it is ready to be used.

TO USE THE STEAMER

1. The steamer may be used as soon as it has built up sufficient pressure to light up the green LED indicator.
2. Using the tweezers or basket, hold jewelry approximately one inch beneath the steam nozzle.
3. Press down on the chrome steam activation lever to release the steam.
4. It is recommended to use short, one or two second bursts to prolong maximum steam pressure.



WHEN IT BECOMES NECESSARY TO REFILL STEAMER TANK

- Turn the unit off by flipping the rear power switch to the “0” position.
- Unplug it from the power outlet.
- **Allow sufficient cooling time of approximately 30 minutes prior to refilling the tank. As a safety feature, the water fill cap has been designed so that it cannot be removed until its tank has sufficiently cooled.**
- While maintaining an arm’s length distance from the appliance, slowly unscrew the water fill cap. As you are unscrewing the water fill cap the remaining pressure will release from around it. Press down on the steam activation lever to more quickly release the remaining steam in its tank. Remove the water fill cap.
- Lift the appliance up by holding both sides. **DO NOT LIFT THE APPLIANCE BY THE STEAM ACTIVATION LEVER.**
- Turn the appliance upside down over a sink to drain any residual water that may be in the steamer tank. To more quickly and fully drain the steamer tank, while holding the appliance upside down, press down on the steam activation lever.
- Follow the instructions 1-6 on the Quick Reference Guide above to refill the BrilliantSpa PRO.

COMPLETE OPERATING INSTRUCTIONS – STEPS 1 THROUGH 12 (WARNING: DO NOT PLUG IN OR TURN ON UNTIL YOU REACH STEP 5)

1. Place the BrilliantSpa PRO upright on your counter.
2. With the steamer unplugged and sufficiently cool, carefully unscrew the water fill cap and then remove it. Place the funnel in the opening where the fill cap was located.
3. Fill the combination water residue collection and fill cup with regular tap water to the MAX FILL LINE and slowly pour it into the steamers funnel. Repeat this a second time so that a total of two cups of water have been added. **IF USED PREVIOUSLY, before refilling it be sure to remove any remaining water in its tank by turning it upside down over a sink or you may accidentally overflow the tank. IF YOU OVERFILL THE TANK, it will not have enough room to create pressurized steam and will sputter**

hot water from its nozzle until the water level in the tank has been reduced to a sufficient level so steam may be produced.

4. Replace the water fill cap by hand tightening. Do not over-tighten. Over-tightening could result in damage to your water fill cap gasket and consequently your steamer will not pressurize properly. **An additional gasket has been supplied with your unit in the event you damage the gasket.**
5. Plug in the BrilliantSpa PRO to a grounded electrical outlet that has a power rating sufficient to operate the appliance. Locate the rear power switch and flip it to the “I” position to turn it on. Within approximately 3 minutes it will automatically heat up the water in its tank creating pressurized steam. The red LED light will indicate that the steamer is heating up the water in its tank and building pressure.
6. When the green LED lights up that indicates that it is ready to be used. Please note that the green LED light will cycle on and off as the steamers thermostat automatically heats up while maintaining constant pressure.
7. Place the jewelry in the handheld basket or while using the tweezers to hold it, firmly yet carefully grasp the item and hold it approximately one inch beneath the steam nozzle.
8. Press the steam activation lever to release steam. The steamer works best when using short, one or two second bursts of steam. Allowing a brief delay between bursts gives the steamer time to rebuild steam pressure. To clean an item on all sides, rotate the item under the nozzle.
Allow the jewelry time to cool before wearing.
9. Inspect the item after cleaning and if it requires additional steam cleaning repeat step #8. For dirtier items, additional steaming time may be required. Pre-soaking the item in hot water will help loosen up the dirt. For faster results, it is also recommended to first use the GemOro Sparkle Spa, or Sparkle Spa Pro personal ultrasonic jewelry cleaner (sold separately). These ultrasonics will quickly loosen up the dirt and pre-clean it prior to steaming.
10. Residual water will collect in the water residue cup as the steam cools. Empty the water as needed.
11. When it is necessary to refill the BrilliantSpa PRO, first turn it off and then unplug it from the power outlet. Allow sufficient cooling time of approximately 30 minutes prior to refilling the tank. When

- removing the water fill cap after it has cooled, always unscrew it slowly at arm's length while allowing the BrilliantSpa PRO to gradually release any remaining pressure in the tank. Then lift the BrilliantSpa PRO by its sides and turn it upside down over a sink to drain any remaining water in its tank. Replace the water fill cap.
12. When you are finished cleaning your jewelry, unplug the BrilliantSpa PRO from the power outlet by grasping the end of the power cord closest to the outlet.
 13. Prior to storing the BrilliantSpa PRO after use, it is recommended to empty the water from its tank. After allowing sufficient cooling time of approximately 30 minutes, remove the water fill cap by slowly unscrewing it while allowing the tank to gradually release any remaining pressure. Then lift the BrilliantSpa PRO by its sides and pour out the remaining water. Replace the water fill cap.

PRECAUTIONS & WARNINGS

1. The BrilliantSpa PRO is specifically designed for cleaning jewelry. Although there are many other cleaning applications for the BrilliantSpa PRO (such as for cleaning dentures, mouth guards, pacifiers, eye glasses, hand tools, small parts, etc.), caution and common sense should be used at all times as the BrilliantSpa PRO could damage the item and/or the operator.
2. Use caution: the steam cleaner releases very hot steam under high pressure. While in use, **never touch the steam nozzle, water fill cap or the area surrounding it, as you may get burnt.**
3. **Be certain that the water fill cap with its built-in safety release valve is screwed on by hand prior to use. Do not over-tighten. Never operate the BrilliantSpa PRO steam cleaner without the water fill cap properly installed.**
4. **The BrilliantSpa PRO steam cleaner may only be used with regular tap water. Never add any type of chemicals or cleaning agents to the water in the tank prior to steaming.**
5. The BrilliantSpa PRO is designed to operate with a specified level of water in its tank. **Do not overfill the steamer tank. To do so will produce a potentially hazardous sputtering of hot water and wet steam.**
6. **Never plug in and attempt to operate the BrilliantSpa PRO without water in its tank.** If the BrilliantSpa PRO runs out of steam during operation, turn it off and unplug it. Then allow

approximately 30 minutes for it to cool prior to refilling the tank. When removing the water fill cap after the BrilliantSpa PRO has cooled, always unscrew it slowly while maintaining an arm's length distance from it, allowing the steamer tank to very gradually release its pressure until fully released.

7. **Never attempt to unscrew the water fill cap and refill the BrilliantSpa PRO steamer tank while it is still hot and under pressure. There is a built-in safety feature that prevents the water fill cap from being removed while the steamer is hot.**
8. Lift or move the BrilliantSpa PRO by grasping it by its sides.
Do not lift the appliance by the steam activation lever.
9. Always turn off and unplug the BrilliantSpa PRO when not in use.
10. **DO NOT IMMERSE IN WATER.**
11. **FOR INDOOR USE ONLY.**
12. **WARNING: Danger of scalding!**

WARNING: to reduce the risk of electric shock, do not remove the appliance's cover. No user serviceable parts are inside. Only authorized service personnel should perform possible repairs of this appliance!

CAUTION

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children do not recognize the dangers that may occur when operating electrical appliances; therefore, keep children away from such appliances.
- This appliance is intended to be used in a jewelry store or for household jewelry cleaning applications.

IMPORTANT - READ BEFORE CLEANING ANY TYPE OF JEWELRY
Prior to using the BrilliantSpa PRO, always confirm if the item may be cleaned with a steam cleaner. While some general guidelines are noted below for what may or may not be cleaned with a steam cleaner, the guidelines are not represented as being complete and are not meant to be used as your final determination as to whether or not the jewelry or other item is suitable for being cleaned by the BrilliantSpa

PRO. Before cleaning any piece of jewelry or gemstone, you should consult with a professional to correctly identify the item you desire to clean and confirm that it is suitable to be cleaned with a steam cleaner. GemOro disclaims, to the maximum extent permissible, (a) any responsibility for damage to jewelry or any other item, and (b) any responsibility for direct, special, incidental or consequential damages under any legal theory.

For more information on jewelry care and cleaning, or assistance with finding qualified professionals with whom you may consult regarding the potential cleaning of your jewelry, visit the following jewelry industry websites:

American Gem Society (AGS) Guide to Fine Jewelry Care
<http://www.ags.org>

Gemological Institute of America (GIA) <http://www.gia.edu/>

Jewelers of America (JA) <http://www.jewelers.org/>

Always inspect the setting for loose stones prior to cleaning. Stones that are insecurely set may fall out when cleaned by a steam cleaner. Prior to cleaning, carefully touch the stone with a small probe (like a toothpick); the stone should not shift or wiggle. **If a stone falls out as a result of being cleaned with a steam cleaner, please be aware that the stone would have eventually fallen out anyway. Most consider it better to have a stone fall out in a reasonably controlled environment as opposed to at random while wearing it.**

The following types of jewelry should only be cleaned by a knowledgeable professional:

- Antique jewelry
- Enamel jewelry
- Paste jewelry (which is common with costume jewelry)
- Costume jewelry
- Jewelry containing stones that have been set with glue

PRELIMINARY GUIDELINE FOR GEMSTONE CLEANING

GEMSTONE	TOUGHNESS	STEAM
Alexandrite	excellent	usually
Amazonite	poor	never
Amber	poor	never
Amethyst	good	risky
Aquamarine	good	usually
Citrine	good	risky
Coral	fair	risky
Diamond	good	usually
Emerald	poor	never
Garnet	fair	never
Iolite	fair	risky
Lapis Lazuli	fair	never
Opal	fair	never
Pearl	good	never
Peridot	fair	never
Ruby	excellent	usually
Sapphire	excellent	usually
Spinel	good	usually
Tanzanite	fair	never
Topaz	poor	never
Tourmaline	fair	risky
Turquoise	fair	never
Variscite	fair	never
Zircon	fair	risky

MAINTENANCE

Your BrilliantSpa PRO is designed to be a very low maintenance appliance. With moderate usage, the tank that is located inside the steamer should be cleaned annually since water will leave calcium or lime residue in the tank that can be flushed out. With the steamer cool and unplugged, pour a small amount of any household cleaner into the tank that is designed to remove hard water deposits. Make certain that it is non-caustic, non-flammable and non-combustible and that it may be used on stainless steel and aluminum. Then fill the tank with tap water, swish around and allow it to remain in the tank as specified in the cleaner's instructions. Then pour out the solution in the tank; flush the tank out thoroughly multiple times with tap water and resume normal use. The exterior of the BrilliantSpa PRO may be cleaned by hand using a soft cloth and a mild household cleaner that is suitable to be used on plastic. Wipe dry using a soft cloth when finished.

WARRANTY

Congratulations on your purchase of the GemOro BrilliantSpa PRO personal steam cleaner for jewelry! Your steamer features a ONE YEAR LIMITED WARRANTY from the date of its purchase by filling out the on-line WARRANTY REGISTRATION FORM at www.gemoroproducts.com/warranty. In the event the BrilliantSpa PRO is no longer available or has been discontinued and warranty coverage is applicable, at the factory's sole discretion, an equivalent steam cleaner may be substituted in place of the defective BrilliantSpa PRO. The purchaser shall incur the cost for return postage, insurance and handling for all warranty and non-warranty repairs. Warranty repairs and/or replacement(s) will be shipped back to the customer FOB Destination to the location of the customer's choosing if located within the Continental United States. Non-warranty repairs will be shipped back to the customer FOB Factory. Should the customer require the repair and/or replacement unit(s) to be shipped outside the Continental United States, the customer will be required to pay any related shipping charges and any related taxes/duties for the respective destination country.

GemOro BrilliantSpa PRO
Warranty Registration
10455 Olympic Drive, Dallas, Texas 75220 USA
800.527.0719 or 214.351.0380 Fax 800.832.9871 or 214.351.1903
www.sparkleexperts.com www.gemoroproducts.com
sales@sparkleexperts.com or support@sparkleexperts.com

GemOro Sparkle Pak Plus®

ULTIMATE JEWELRY CLEANER
CONSUMER HOME-USE FORMULA IN
PRE-MEASURED PACKETS

- For personal-use with ultrasonics, sonics, spray bottle and soak-bath cleaning.
- Instantly cleans platinum, gold, silver, metal watch bands, base metal, diamonds, gemstones, fine jewelry, fashion or costume jewelry, and more.
- Includes 10 packets of super-concentrated jewelry cleaner. Combined with water, makes almost 2 gallons of solution for you to use and reuse in a variety of applications!



Box of 10 Item #0937

GemOro Sparkle Wand

ON-THE-GO JEWELRY CLEANER

Remove cap, twist end to wet brush with specially formulated jewelry cleaning solution. Rub brush on diamonds and jewelry. Rinse off and dry. Instantly cleans and maintains the like-new sparkle of your diamonds, rubies, emeralds, sapphires, plus restores the luster of gold, silver and platinum like magic. Safe for ALL jewelry.

Item #0912



GemOro Sparkle Safe

CLEANS ALL JEWELRY

Our all purpose secret formula safely cleans and brings back the sparkle to all jewelry. Perfect for diamonds, gold, and platinum, plus all soft and porous stones like pearls, and opals too. Contains no harsh or toxic chemicals. Includes basket and mini-brush for intricate cleaning. Item #0917



GemOro Mega-Sparkle

JEWELRY POLISHING & ANTI-TARNISH CLOTH

Polishes gold, silver and platinum / restores maximum sparkle, luster and shine to jewelry while inhibiting tarnish. Contains No Harsh Chemicals or Abrasives. Non-Toxic & Environmentally Friendly. Item #1649



GemOro SparkleSpa®

PERSONAL ULTRASONIC CLEANER

Cleans quickly and easily with powerful, yet gentle ultrasonic waves!

- True professional grade ultrasonic jewelry cleaner for the home
- Approximate 20oz (600ml) tank capacity
- Powerful 42,000Hz energy producing sound waves per second
- Digital timer
- No scrubbing or polishing required - cleans in only minutes
- 3 Programmable cleaning cycles - 180, 300 and 600 seconds
- Includes a removable basket and bracelet / watch holder
- 1 Year limited replacement warranty

Item #1783





GemOro Sparkle Spa Pro®

PRESTIGE SERIES PERSONAL ULTRASONIC JEWELRY CLEANER

ADVANCED PROFESSIONAL FEATURES:

- True professional grade ultrasonic jewelry cleaner for the home
- Approximate 25oz (750ml) tank capacity
- Powerful 42,000Hz energy producing sound waves per second
- Digital timer
- Auto shut-off function - 5 Cleaning cycles
-90, 180, 280, 380 and 480 seconds
- Safely cleans most jewelry using regular tap water (for best results
use GemOro Sparkle Pak Plus solution Item #0937 sold separately)
- Bright blue LED illuminated stainless steel tank
- Auto-opening transparent evaporation-free cover
- Quiet solid-state circuitry
- Elegant slate gray or black contoured design with chrome accents
- Removable basket and bracelet / watch holder included
- 50 / 60Hz
- 1 Year limited replacement warranty

Slate #1791 / Black Item #1790



10455 Olympic Drive, Dallas, Texas 75220 USA

Tel 800.527.0719 or 214.351.0380

Fax 800.832.9871 or 214.351.1903

www.sparkleexperts.com

www.gemoroproducts.com

sales@sparkleexperts.com

support@sparkleexperts.com