

Hotkeys Chart

Here's a list of the hotkeys for IPEVO Visualizer:

(i) Changing Visualizer's window/UI size

Function	Mac	Windows
Toggle between full screen and windowed mode	option + enter	Alt + Enter
Exit full screen	esc	Esc
Switch between larger/normal User Interface	option + M	Alt + M

(ii) Open a new Visualizer window

Function	Mac	Windows
Open a new window	cmd+N	Ctrl+N

(iii) Controls

Function	Mac	Windows
Focus	F	F
Turn LED light on/off	L	L
Increase exposure	]	]
Decrease exposure	[	[
Lock/unlock exposure	\	\

Manual focus (Infinity)	;	;
Manual focus (Macro)	‘	‘
Increase white balance	.	.
Decrease white balance	,	,
Resume to auto white balance	/	/
Display/hide line marker	ctrl + A	Ctrl + A
Show/hide gridlines	ctrl + D	Ctrl + D
Cycle through different video filters	ctrl + F	Ctrl + F
Show/hide camera's status	ctrl + I	Ctrl + I
Freeze/resume live view	ctrl + P	Ctrl + P
Open Text-To-Speech window	ctrl + T	Ctrl + T
Zoom in	ctrl + cmd + ↑	Ctrl + ↑

Zoom out	ctrl + cmd + ↓	Ctrl + ↓
Rotate clockwise	ctrl + cmd + →	Ctrl + →
Rotate counterclockwise	ctrl + cmd + ←	Ctrl + ←
Horizontal mirror	ctrl + cmd + H	Ctrl + H
Vertical mirror	ctrl + cmd + V	Ctrl + V
Reset zoom, rotate, and mirror	ctrl + cmd + R	Ctrl + R
Toggle between different function modes	ctrl + 1~9	Ctrl + 0~9 (Windows 8 and above) Ctrl + 1~9 (Windows 7)
Perform the primary function of the respective function mode	spacebar	spacebar